

# 4 LEG CHAIRS

Albury Side, Albury Arm, Bronte, Chevron, Coogee & Stockholm Metal & Timber Chairs



scan me

## PARTS:

## TOOLS (NOT INCLUDED):

**SHELL (A)**

Albury Side   Albury Arm   Bronte   Chevron   Coogee   Stockholm

*Shells compatible with all standard chair frames.*

1pc

**FRAME (B)**

Metal / Timber  
Frame

1pc

**4MM HEX HEAD (C)**

4pc

**WASHER (D)**

4pc

**THREADLOCK**

**IMPACT DRILL**

We strongly recommend applying thread lock to the full length of all screws and using an impact drill. Scan the QR code with a phone or tablet to access the assembly video.

**WARNING:**  
Always take care with an impact drill gun, especially when screwing into the frame.

## INSTRUCTIONS:

**STEP 1:**

**COMPLETE:**