

D720MM

Danube, Porto, Prague & Rome Table & Drybar Bases



scan me

PARTS:

SPIDER (A)

1pc

BASE (B)

1pc

COLUMN (C)

1pc

5MM HEX HEAD (D)

8pc

TOOLS (NOT INCLUDED):

THREADLOCK

IMPACT DRILL

We strongly recommend applying thread lock to the full length of all screws and using an impact drill. Scan the QR code with a phone or tablet to access the assembly video.

WARNING:
Always take care with an impact drill gun, especially when screwing into the spider (cross member).

INSTRUCTIONS:

STEP 1:

STEP 2:

STEP 3:

COMPLETE: