

# TEXAS / MARCO / LUGANO / KANSAS

**ez** ASSEMBLY INSTRUCTIONS

Metal Frame Chairs



scan me

**PARTS:**

**TOOLS (NOT INCLUDED):**

<p><b>FRAME (A)</b></p> <p>1pc</p>	<p><b>BACK (B)</b></p> <p>Texas Marco Lugano Kansas</p> <p>*Veneer or Upholstered Compatible</p> <p>1pc</p>
<p><b>SEAT (C)</b></p> <p>Veneer Upholstered</p> <p>1pc</p>	<p><b>WASHER (D)</b></p> <p>*Use with veneer seats</p> <p>4pc</p>
<p><b>HEX HEAD L25MM (E)</b></p> <p>*Veneer Back</p> <p>4pc</p>	<p><b>HEX HEAD L30MM (E)</b></p> <p>*Upholstered Back</p> <p>4pc</p>
<p><b>HEX HEAD L35MM (E)</b></p> <p>*Veneer Seat</p> <p>4pc</p>	<p><b>HEX HEAD L40MM (E)</b></p> <p>*Upholstered Seat</p> <p>4pc</p>

<p><b>THREADLOCK</b></p>	<p><b>IMPACT DRILL</b></p>
--------------------------	----------------------------

We strongly recommend applying thread lock to the full length of all screws and using an impact drill. Scan the QR code with a phone or tablet to access the assembly video.

**WARNING:**

Always take care with an impact drill gun, especially when screwing into the pads. You will need to use the appropriate screw combinations for the different seat and back types.

**INSTRUCTIONS:**

<p><b>STEP 1:</b></p>	<p><b>STEP 2:</b></p>	<p><b>COMPLETE:</b></p>
-----------------------	-----------------------	-------------------------