

TEXAS / MARCO / LUGANO / KANSAS

ez ASSEMBLY INSTRUCTIONS

Metal Frame Stools



scan me

PARTS:

TOOLS (NOT INCLUDED):

FRAME (A) 1pc	BACK (B) Texas Marco Lugano Kansas *Veneer or Upholstered Compatible 1pc
SEAT (C) Veneer Upholstered 1pc	WASHER (D) *Use with veneer seat 4pc
HEX HEAD L25MM (E) *Veneer Back 4pc	HEX HEAD L30MM (E) *Upholstered Back 4pc
HEX HEAD L35MM (E) *Veneer Seat 4pc	HEX HEAD L40MM (E) *Upholstered Seat 4pc

THREADLOCK 	IMPACT DRILL
-----------------------	-------------------------

We strongly recommend applying thread lock to the full length of all screws and using an impact drill. Scan the QR code with a phone or tablet to access the assembly video.

WARNING:

Always take care with an impact drill gun, especially when screwing into the pads. You will need to use the appropriate screw combinations for the different seat and back types.

INSTRUCTIONS:

STEP 1: 	STEP 2: 	COMPLETE:
--------------------	--------------------	----------------------