

TORINO

Timber Chairs & Stools

ez ASSEMBLY
INSTRUCTIONS



scan me

PARTS:

TOOLS (NOT INCLUDED):

FRAME (A)

1pc

BACK (B)

1pc

SEAT (C)

1pc

4MM HEX HEAD L25MM (D)

4pc

4MM HEX HEAD L75MM (E)

4pc

WASHER (F)

4pc

SPLIT WASHER (G)

4pc

DOWEL (H)

2pc

PLUG (I)

4pc

THREADLOCK

WOOD GLUE

IMPACT DRILL

RUBBER Mallet

We strongly recommend applying thread lock to the full length of all screws, using Wood glue for the plugs and using an impact drill. Scan the QR code with a phone or tablet to access the assembly video.

WARNING:
Always take care with an impact drill gun, especially when screwing into the pads. You will need to use the appropriate screw combinations for the different seat and back types.

INSTRUCTIONS (UPHOLSTERED SEAT & BACK):

STEP 1:

STEP 2:

STEP 3:

COMPLETE: